

# FALCON WATERFREE URINALS

## Cleaning and cartridge change instructions



### CLEANING



Remove debris from bowl



Spray (mist) Falcon-recommended\* cleaner onto bowl



Wipe clean and dry



Never dump cleaning solutions or other chemicals into bowl

*When Should a Cartridge Be Changed?*

Blue sealant appears around the diverter shield.



or

Fluid flows very slowly into the cartridge.

or

Fluid does not drain into the cartridge.

### CARTRIDGE CHANGE



Verify contents of kit



Insert key into cartridge



Turn key to left to unlock



Lift cartridge and drain all free liquids



Place cartridge into disposal bag and dispose



Flush housing with warm soapy water



Wipe clean inner stainless steel rim



Insert new cartridge into housing and turn key to right to lock



With diverter shield removed, fill cartridge with 1 quart or more of water until there are no air bubbles



Add blue sealant (allow time to drain into cartridge)



Spray (mist) Falcon-recommended\* cleaner and wipe clean



Snap the diverter shield into place

**\*Falcon-recommended cleaners:** <http://www.falconwaterfree.com/literature/>

Falcon Customer Experience Department: 866-975-0174 (toll free) • 616-954-3570 • Fax 616-954-3479 • [service@falconwaterfree.com](mailto:service@falconwaterfree.com)